



Materials :-

2 no. layers of Cellcore HXB panels.

Notes :-

- The appropriate specification of Cellcore and Heaveguard panels should be selected based upon the information provided in the relevant Cordek technical guidance.
- Cellcore panels should be installed on a smooth, flat, well compacted surface comprising of a sand / cement or concrete blinding.
- The 2nd layer of Cellcore panels should be installed so that the joints are staggered and offset against the joints of the 1st layer.
- Joints between individual Cellcore panels in the 2nd layer should be sealed using Cordek formwork tape.
- Care should be taken not to surcharge the Cellcore panels with either reinforcement or concrete.

Standard Detail



Tel : 01403 799600

Email : sales@cordek.com

Drg. Title:
Standard Ground Beam Detail : Cellcore HXB -
Double Stacked - Very High Heave Potential

Drawn: SP

Date: Feb.2021

Scale: NTS

Dra. No. ENG/GH/CELL/HXB/VHH

Rev: A