



NB :- The grade of Cellcore HX B panel required may vary along the length of the drainage run as the depth of the concrete infill increases to accommodate the fall of the pipe. Detail to be read in conjunction with Standard Detail Drg No. ENG/GH/CELL/001.

Standard Detail



Tel : 01403 799600

Email : techsupport@cordek.com

Drg. Title:
Standard Underslab Drainage Detail - Side View - Cellcore

Drawn: SJP

Date: Nov.2017

Scale: NTS

Drg No. ENG/GH/CELL/006

Rev.

Products :-

Cellcore HX B.
Filcor EPS.

Notes :-

- The appropriate specification of Cellcore panels should be selected based upon the information provided in the relevant Cordek technical guidance.
- Cellcore panels should be installed on a smooth, flat, well compacted surface comprising of a sand / cement or concrete blinding.
- Where necessary, joints between individual Cellcore panels should be sealed using Cordek formwork tape.
- Care should be taken not to surcharge the Cellcore panels with either reinforcement or concrete.