



Standard Detail



Tel : 01403 799600
 Email : techsupport@cordek.com

Drg. Title:
 Standard Underslab Drainage Detail - Cellcore

Drawn: SJP

Date: June.2017

Scale: NTS

Drg No. ENG/GH/CELL/001

Rev. - 002

Products :-

Cellcore HX S & HX B.

Notes :-

- The appropriate specification of Cellcore and Heaveguard panels should be selected based upon the information provided in the relevant Cordek technical guidance.
- Cellcore panels should be installed on a smooth, flat, well compacted surface comprising of a sand / cement or concrete blinding.
- Where necessary, joints between individual Cellcore panels should be sealed using Cordek formwork tape.
- Care should be taken not to surcharge the Cellcore panels with either reinforcement or concrete.