



| Cellcore 200mm HG 50/65  |                 |            |
|--|-----------------|------------|
| Panel Depth  | Max. Clear Void | Slab Depth |
| 200mm  | 100mm           | 0-1940mm   |
| Cellcore HX S, HX B & HX Plus options are available upon request |                 |            |

**Standard Detail**



Tel : 01403 799600  
 Email : techsupport@cordek.com

Drg. Title:  
 Standard Slab Detail :  
 Cellcore HG - Medium Heave Potential

Drawn: SJP

Date: June.2017      Scale: NTS      Rev. - 002

Drg No.ENG/GH/CELL/200 HG 50/65/SLAB

**Products :-**

Cellcore 200mm HG 50/65.

**Notes :-**

- The appropriate specification of Cellcore and Heaveguard panels should be selected based upon the information provided in the relevant Cordek technical guidance.
- Cellcore panels should be installed on a smooth, flat, well compacted surface comprising of a sand / cement or concrete blinding.
- Where necessary, joints between individual Cellcore panels should be sealed using Cordek formwork tape.
- Care should be taken not to surcharge the Cellcore panels with either reinforcement or concrete.